

Electronic Phone Covers

SUBLIMATION

Printing

When using SubliJet refer to the PowerDriver Manual or if using ArTainium or another brand of ink use the instruction manual provided from the vendor you purchased your ink from. All images should be MIRRORED unless specified below.

Important

When the image is printed, it may look dull on the paper—this is normal. Trim the image to make it easier to position on your item. Secure your image to the object with heat tape to keep it from slipping or shifting. Protective plastic sheet on the insert must be peeled off before use with CL Hard Surface I or sublimation.

When pressing is done, Open the press slowly and gently remove the object and remove the paper (be careful not to let the paper shift across the surface of the object, or you may create a "ghost" image). When the object is removed from the press, just let it cool.

Heat Press Setup

Set your heat press to 360F. Before pressing, test the pressure on a blank steel insert. The pressure should be light. Ensure that your press has reached 360F before pressing.

Protect your heat press with at least two pieces of plain paper underneath your substrate and on top of your substrate. You can simply fold a full sheet in half and that should be sufficient. **DO NOT ALLOW ANY PART OF THE METAL INSERT EDGES TO BE IN DIRECT CONTACT WITH YOUR HEAT PLATEN**

Pressing

Press Temperature: 360F | Press Time 45 seconds

- 1.) Place two pieces of plain paper on your heat press.
- 2.) Place imaged sublimation paper on the heat press with image face up.
- 3.) Place white metal insert on top of sublimation paper with printable side (white side) face down.
- 4.) Place two pieces of plain paper on top of Aluminum insert.
- 5.) Close your heat press
- 6.) Once pressing is done, immediately peel off sublimation paper.
- 7.) Leave steel insert on a cold surface to cool.

Application to Phone Cover

Attaching the insert to your Electronic Phone Cover:

- 1.) Attach the imaged metal insert onto the cover by removing the protective covering to expose the adhesive and firmly set the insert onto the cover.

For Technical Support and to Re-Order

Tel: 1-800-565-5686 | Fax: 1-800-565-5622 | www.jotopaper.com
Blaine WA, Las Vegas NV, Akron OH, Nashville TN, Coquitlam BC, Mississauga ON

Electronic Phone Covers

L A S E R T R A N S F E R P A P E R

Printing

- Print Mirror Image
- Print using heavy to Label mode depending on the printer you are using.
- Once printed, ensure that the toner has adhered properly to the paper.

Important

Trim the image to make it easier to position on your item. Secure your image to the object with heat tape to keep it from slipping or shifting. Protective plastic sheet on the insert must be peeled off before use with CL Hard Surface I or sublimation.

It is very important that heavy and even pressure is applied to the substrate and paper. Also when peeling, you do so with a smooth consistent motion.

Heat Press Setup

Set your heat press to 330F. Before pressing, test the pressure on a blank steel insert. The pressure should be heavy. Ensure that your press has reached 330F before pressing.

Protect your heat press with at least two pieces of plain paper underneath your substrate and a foam pad on top of your substrate. **DO NOT ALLOW ANY PART OF THE METAL INSERT EDGES TO BE IN DIRECT CONTACT WITH YOUR HEAT PLATEN**

Pressing

Press Temperature: 330F | Press Time 180 seconds

- 1.) Place two pieces of plain paper on your heat press.
- 2.) Place white metal insert on heat press with printable side (white side) face up.
- 3.) Place imaged CL HS 1 on top of Aluminum insert with image face down
- 4.) Place a foam pad on top of CL HS 1 Paper.
- 5.) Close your heat press
- 6.) Once pressing is done, leave on a cold surface to cool
- 7.) Peel transfer paper warm/cold

Application to Phone Cover

Attaching the insert to your Electronic Phone Cover:

- 1.) Attach the imaged metal insert onto the cover by removing the protective covering to expose the adhesive and firmly set the insert onto the cover.

For Technical Support and to Re-Order

Tel: 1-800-565-5686 | Fax: 1-800-565-5622 | www.jotopaper.com
Blaine WA, Las Vegas NV, Akron OH, Nashville TN, Coquitlam BC, Mississauga ON