

# 17oz Travel Mug

## SUBLIMATION

### Printing

When using SubliJet refer to the PowerDriver Manual or if using ArTainium or another brand of ink use the instruction manual provided from the vendor you purchased your ink from. All images should be MIRRORED unless specified below.

### Important

When the image is printed, it may look dull on the paper—this is normal. Trim the image to make it easier to position on your item. Secure your image to the object with heat tape to keep it from slipping or shifting.

When pressing is done, Open the press slowly and gently remove the object and remove the paper (be careful not to let the paper shift across the surface of the object, or you may create a “ghost” image).

### Heat Press Setup

The **11oz mug element** must be installed in order to sublimate to the 17oz travel mug. Do not put the entire travel mug into the press. Only sublimate the white metal insert on the outside of the travel mug. When you receive the travel mug, the bottom is not screwed on to allow for easy removal of the white metal insert.

Before pressing, test the pressure using a blank one. Ensure that your mug press has reached the idle or press temperature before sublimating your travel mug.

**Do not use excessive pressure.** Doing so will damage your mug press and damage your item.

### Pressing

#### OVERVIEW

**Press Temperature: 365F for 45 secs**

**Light Pressure, hot peel**

**Recommended Printable area when using a mug press: Approx. 6"W x 3.3"H**

- 1.) Remove the white stainless steel insert from the travel mug.
- 2.) Design your image and print it out on sublimation paper with sublimation ink printer.
- 2.) Tape imaged sublimation paper onto your the white stainless steel insert
- 3.) Set the mug press at **365F** for 45 seconds. If your press has an idle and press temperature setting, adjust the time accordingly
- 4.) Ensure mug press has reached temperature, Place the insert into your mug press.
- 5.) Close Mug Press.
- 6.) Once pressing is done, open mug press, and take the insert out of the press.  
Use gloves or heat resistant cloth to handle the hot insert
- 7.) Peel sublimation paper off. and leave it to cool off completely.
- 8.) Install the insert onto the travel mug, then screw the bottom on.

**Caution: Metal Insert is extremely hot when in the mug press, do not handle with bare hands**

Note: Temperature and time settings are only a guide/starting point, some mug presses may require some fine tweaking of the temperature and time.

**For Technical Support and to Re-Order**

Tel: 1-800-565-5686 | Fax: 1-800-565-5622

[www.jotoimaging supplies.com](http://www.jotoimaging supplies.com)