

CL 100

APPLICATION INSTRUCTIONS

STEP BY STEP

Note:

See enclosed diagram for printable side

Step 1

Feed material into laser printer so that the printer is printing on the printable side (see above note).

Step 2

Design your image and and resize if necessary

Step 3

Prepress fabric for 5-10 seconds

Step 4

Place on shirt with image face down.

Step 5

Heat apply the transfer onto the fabric. Press at 360-400F at 10-18 seconds. Use High pressure

Step 6

Release press, gently tug at side of shirt and peel backing paper off while hot. After peeling off the backing paper, gently tug sideways along each side of the image. This will soften the feel of the transfer on the shirt.

APPLICATION

| | | |
|--------------|---------------------|---------------------|
| Printer | Canon, Minolta | Xerox, Ricoh |
| Paper Mode | Heavy to Label* | Heavy to Label* |
| Image | Mirror | Mirror |
| Press Time: | 10-12 sec. | 15-18 sec. |
| Temperature: | 360-380F (180-190C) | 380-400F (190-200C) |
| Pressure: | High | High |
| Peel: | Warm (3 secs) | Warm (3 secs) |
| Wash Temp.: | Up to 105F (40C) | Up to 105F (40C) |

*These settings are recommended, you may need to conduct your own tests
All technical information and recommendations are based on tests we have conducted.
Users should conduct their own tests before proceeding

NOTES

Recommended Fabrics

White or Light Colored
100% cotton
100% polyester
Poly/cotton blends
Polyester knits
Polyester mesh
Poly/foam & cotton caps
Satin

Accessories Required

Computer, Color Laser Printer,
Heat Press.

Printable side

See enclosed diagram for printable side

Pressure Settings

To ensure that the coating has properly fused with the fabric, we recommend to use maximum pressure. If this paper is applied with inadequate pressure, the transfer will not wash well.

Peeling

This paper is to be peeled 3 seconds after pressing. Gently tug along either side of the image, this will soften the feel of the transfer on the shirt.

MousePads

For mouse pads use medium pressure and press at 385F for 10 seconds and peel hot.

Care Instructions

Wait 24 hours before washing. Machine wash using mild detergent. Do not use bleach or other aggressive cleaning agents. Cannot be dry cleaned. Wash Temperature cannot exceed 105F

Storage

New CL has an indefinite shelf life when stored at room temperature. Keep away from direct heat, sunlight and humidity.